



# Magic corner insrtuction(Right side)




## Optional basket



| Item |   |
|------|---|
| 1    | Install the A part of backside sliding frame  |
| 2    | Install the B part of guide plate   |
| 3    | Install the C part of corner fixing plate   |
| 4    | Install the D part of swing drawbar   |
| 5    | Install the F part of door connector  |
| 6    | Inset the drawbar cover on the E part of swing frame into D part of swing drawbar                           |
| 7    | Inset the rotation shaft under the E part of swing frame into the hole on the C part of corner fixing plate |
| 8    | Inset the drawbar cover on the E part into the groove on the B part of guide plate                          |
| 9    | Install the cover of upside rotation shaft M, then rotate 90 degree to lock                                 |
| 10   | Inset the drawbar D into the backside sliding frame A part  |
| 11   | Inset the lower detent at the outside of door connector F part into the groove on the E part                |
| 12   | Inset the upside detent at the outside of door connector F part into the groove on the E part               |
| 13   | Inset the lower detent at the inside of door connector F part into the groove on the E part                 |
| 14   | Fine tune the position of the door by the adjustable screw on the E part                                    |
| 15   | Adjust the screw J to control the open angle of E part  |




### 1, part list:









## Insrtuction



